







**Dinkmar 3013-B
Cylinder Mounting
Can Be Add for Power
Exhaust Tube Assembly**

DimkMar Turn Table Assembly 108-B



**Dinkmar Self-Contain
Mule HCN**

DinkMar Leaf Master
Intake Nozzel

291-B 12" Hose

291-B 16" Hose


291-B 18" Hose

Dinkmar Rubber Nozzel Boot


520-B 16" Steel

520-B 16" Rubber



520-B 18" Rubber




Dinkmar 465-B 8" Ring
Dinkmar 466-B 12" Ring
Dinkmar 293-B 16" Ring
Dinkmar 467-B 18" Ring




Dinkmar Drive Shaft Guard
483-B For The Guard only
483-B1 For The Guard and Hardware
3/8" Thread Rod, Washers, and Lock Nuts



OPTIONAL TUBE DIAMEMTERS		
PART NO.	PLATE HOLE DIA	HOSE DIA
126-B1	11-7/8"	12"
126-B2	15-7/8"	16"
126-B3	17-7/8"	18"





Dinkmar Rear Scoll Assembly 500-B



Rear Scroll 501-B

Bearing Support 490-B

Support Gussett 485-B1


Turn Table 485-B

Turn Table Base
485-B





Support Gussett

Support Gussett





Bearing Support
and Rear Scroll


Dinkmar Turn Table Hold Down Clamps
This Item Is Located On The Back Side
Part #350-B 2 parts per Turn Table



Dinkmar Turn Table Hold Down Clamps
This Item is Located on the Side and Front
Part #231-B 4 parts per Turn Table




Power Parting Jack Assembly
Complete Less Jack Wheel
Part #142-B




Dinkmar Steel Exhaust Tube
Standard length is Seven (7) feet long
Power Cylinder Mount is Standard
Any other Size will be a Special Order


Square Frame Weldment
DinkMar 484-B




Rectangular Exhaust Tube Assembly
DinkMar 346-B Parts Number
Gledhill 7654-C



Steel Round Exhaust Tube Assembly
Dinkmar 12" Round 529-B
Dinkmar 16" Round 531-B
Dinkmar 18" Round 533-B



PD-766



Standard Parts list for Gledhill Leaf Loader The machines that was built till 1995

List of Common parts for Gledhill & DinkMar

A. Fan Shaft

B. Carriage Bolts

C. Liner Assembly

2 3/16" Link Belt Pillow Has been Replace with

2 3/16" Brownies for all DinkMar Machine

2 3/16" Hub City for all Recon. & Econo Line

DinkMar fan Assembly is 252-B 3/8" AR400

Size from 25" to 34"


ALWAYS REFER TO SERIAL NUMBER WHEN ORDERING REPAIR PARTS

Please Note that the DinkMar
Also can Produce parts for
other make and model of Leaf
Loader machine that will meet
your needs and service cost


ADDED 2 NOV. 72



**Dinkmar 458-B Swing Arm Bearing
Leaf Master Machine & Self Contain
Mule HCN Machine**





DinkMar 211-B Replacement Welded On Ear Bracket



**DinkMar P-423-1A Brass Bushing
New Part 2005 Leaf Master
Self-Contain Mule HCN**


DinkMar 3010-B Slide Tube for the Bix Six Machine
DinkMar 3008-B Inner Tube for A-Frame and Leaf Master
DinkMar 3009-B Hitch Assembly is Used on all Machine





The diagram shows a vertical boom on the left and a horizontal boom at the top. A dashed line indicates a latch hook mechanism at the end of the horizontal boom. A leader line points from the text to this mechanism.


**Dinkmar 3007-B Subport
Boom Assembly with
Latch Hook**




The diagram shows a vertical support boom on the right. At the top, a U-bolter is shown securing the boom to a horizontal structure. A leader line points from the text to the boom.

**DinkMar Support Boom Used on
Leaf Master Machine
Self Contain Machine Mule HCN**


DinkMar 3006-B Swing Arm Assembly
Leaf Master Machine
Self-Contain Mule HCN




DinkMar 158-B Adjustment Bolts Assembly
Assembly for all Machine
DinkMar 1997- Today
Gledhill Machine



DinkMar 3004-B Swing Arm Bracket Assembly
Leaf Master Machine
Self-Contain Machine Mule HCN




**DinkMar Belt Guard Assembly for all Machine
Produce since 1997. Gledhill machine can
be change to new belt guard**




DinkMar 3002-B Exhaust Elbow
Assembly Big Six Machine



DinkMar 3001-C 45 Degree Scroll
Assembly Big Six Machine

DinkMar 3003-B Square to Round
Exhaust Bix Six Machine









Dinkmar 451-B Swing Arm Assembly



Dinkmar 446-B used for Pulley Assembly Located motor shaft and also used on old style Gledhill fan.



**DinkMar P-423-1A
Brass Bushing Install New
for machine built 2005 year**



**DinkMar 423-B Bearing
Used on Leaf Master Sc- Mule
Machine**

DinkMar 7651-C Elbow Assembly

K-7651-C Elbow Kit Assembly

A. 7651-C Elbow

B.108-B Turn Table

C.P-1761 Cylinder

D.Hardware

**All 360 Degree Elbow
has Mounting Bracket
welded in place**

